

# Motion Sensor Alarm with Remote Control

31224c  
Elpine™  
A NAME YOU CAN TRUST!



## INSTRUCTIONS

- Position the alarm in the selected location, within 5m range of area/object to be secured (eg. motorcycle in garage or doorway).
- Alarm can be placed on wall using the fitting bracket supplied or standing on a firm and level base.
- To set the alarm, point a remote control towards the unit (within 7m range) and press button once. The alarm will “chirp” and the GREEN LED on the alarm will illuminate for about 15 seconds. This is the Exit delay phase, giving user time to leave the area.
- When the RED ‘EYE’ illuminates, the alarm is set, any movement within range will cause the alarm to sound.
- To switch alarm off, point the remote control towards the unit and press button once. The alarm needs to be switched off within a few seconds of entering the secured area.. During this entry delay a red led will flash.
- If the alarm is activated by any motion, the alarm will sound for approx. - 040 seconds and then return to set. The alarm can only be turned off using the remote controls.



Elpine B20 3BT

