INSTRUCTION MANUAL

Read all the instruction carefully before you use the appliance and keep it for future use.



RECHARGEABLE SUPER BRIGHT 3 WATT LED SPOTLIGHT



• LED unlike a bulb, no replacement needed

- More energy efficient than other types of bulbs
- Equipped with a sealed lead acid battery
- Dual recharge, either AC/DC charger or 12v DC car plug adaptor (both included)
- Camping, fishing, hunting & outdoor uses.





Elpine B20 3BT UK

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, to reduce the risk of fire, electrical shock or injury, please read and understand all instructions before using the spotlight.

WARNING

- Close supervision is necessary when any appliance is used by or near children. Do not allow to be used as a toy.
- To protect against risk of electrical shock, do not put unit or charger in water or other liquid.
- Do not put this unit in a fire or near any flammable object as this may cause explosion.
- Do not operate any appliance with damaged cord or charger or after this appliance malfunctions, is dropped into water or is damaged in any manner. Return the appliance to any authorised service facility.
- Do not abuse the cord. Never carry the charger by the cord or yank to disconnect from an outlet; instead grasp the charger and pull to disconnect. Keep cord away from heated surfaces. Do not pull cord around sharp edges or corners.
- Do not allow the cord to hang over the edge of a table or counter or touch hot surfaces. The unit should be placed or mounted away from sinks and hot surfaces.
- Do not use an extension cord. Plug the charger directly into an electrical outlet.
- Do not use excessive force on the product as it may cause permanent damage to the unit.
- Use the charger only in a standard electrical outlet.
- Do not attempt to use the charger with any other product; do not attempt to charge this product with any other charger. Use only the charger supplied by manufacturer to recharge.
- Unplug the charger from outlet before any routine cleaning or maintenance.
- Always keep the lantern fully charged when not in use. Fully recharged, the battery can be stored for up to 3 months without recharging. Storage of the lantern for more than 6 months without recharging can damage the battery.
- It is important to recharge the lantern as soon as possible after each usage.
- Do not shine directly into eyes.
- The sealed battery in this unit contains lead and must be recycled or disposed of properly.

PRODUCT FEATURES

- Swivel handle & stand
- Super bright 3 Watt LED light
- Two brightness modes
- Battery service time up to 4 hours for strong brightness or 8 hours for standard brightness.
- Equipped with rechargeable sealed acid battery and an AC/DC charger (included)
- Using 12V DC car plug adaptor for charging (included)



OPERATION

- Push the handle button and turn the handle to upper or lower position. Upper pistol profile for pin pointing long range objects, lower lantern profile for searching around.
- Charge the battery prior to initial use. (see RECHARGING THE BATTERY)
- Turn the lantern ON and OFF by the switch on the main body. ON --> standard brightness --> high brightness --> OFF

RECHARGING THE BATTERY

- Before recharging the battery, turn the function switch to off position.
- Before using the spotlight for the first time, charge the battery for 12 continuous hours using the AC battery charger.
- Plug the AC charger unit into any electrical outlet, and plug the other end of cord adapter to the DC jack of the spotlight. The Red LED lights on to indicate the charger is working, When the battery is fully charged, green LED will illuminate, the time required to fully charge the battery is around 12 hours.
- Plug the car plug charger unit into the cigarette lighter socket on your car, and plug the other end of cord adapter to the DC jack of the handle of spotlight. The Red LED lights on to indicate the charger is working, When the battery is fully charged, green LED will illuminate, the time required to fUlly charge the battery is around 12 hours.
- It is important to recharge the spotlight as soon as possible after each usage.
- Do not completely discharge battery before recharging. Deep discharge will decrease battery life.
- To ensure the battery will not be fully exhausted when the lantern is not in use or in storage, recharge the battery every 3 months.
- If operating time decreases significantly, a replacement battery is recommended. To replace or obtain a new battery, contact your local Authorised Service Centre.

NOTE

- To assure product SAFETY and RELIABILITY, repairs, maintenance and adjustment should be performed by authorised service centres or other qualified service organisations, always using identical replacement parts.
- Make sure the spotlight is completely dry before using it.

MAINTENANCE

Use only mild soap and damp cloth to clean the lantern. Never let any liquid get inside the lantern; never immerse any part of the spotlight into a liquid.

CORRECT DISPOSAL OF THIS PRODUCT



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

RECHARGEABLE SUPER BRIGHT 3 WATT LED SPUTLIGHT







Elpine B20 3BT UK